

Warranty

A. Warranty Registration must be completed and mailed to Technomad Inc. ("Technomad") within 30 days of your purchase in order for you to receive the Extended Warranty terms described below. However, failure to return the card will not void the one-year basic warranty.

B. Technomad warrants all materials and workmanship, for a period of one year from the original date of purchase. If you complete the optional questionnaire portion of the Product Registration Card, the warranty will be extended as follows:

- The molded plastic loudspeaker body and lid will be warranted for a total of ten years
- All exterior cabinet hardware (catches, strikes, D-rings, and handles) will be warranted for a total of five years.
- All electronic components (wiring, connectors, crossover, speaker drivers, and switches) will be warranted for a total of two years against manufacturing defects.

Failure of any electronic speaker component due to excessive input signal (including but not limited to voice-coil burn-out) is not covered by this warranty. If any defects are found in the materials or workmanship during the applicable warranty period, Technomad, at its option, will repair or replace the product.

C. Service and repairs of Technomad products are to be performed ONLY at the factory (see D below) unless otherwise authorized IN ADVANCE by the Technomad Service Department. Unauthorized service, repairs or modifications will void this warranty.

D. To obtain factory service:


1. Call Technomad at 1.800.464.7757 x 4, 9AM to 5PM EST, Monday through Friday to obtain a Return Authorization number (RA). You can also email us at info@technomad.com. Products returned not displaying a RA number on the outside of the carton will be refused.
2. Pack the product in a securely taped, doubled corrugated cardboard box.
3. Ship the product freight prepaid to:

Technomad Inc.
58 Old Amherst Road, Sunderland MA 01375 USA
RA# _____

E. Technomad reserves the right to inspect any products which may be the subject of any warranty claims before repair or replacement is carried out. Technomad may, at its option, require proof of the original date of purchase in the form of a dated copy of the original seller's invoice or sales receipt. Final determination of warranty coverage lies solely with Technomad, Inc. Any Technomad product deemed eligible for repair or replacement under the terms of this warranty will be repaired or replaced within thirty day of its receipt by Technomad at our factory. Products that do not meet the terms of this Warranty will be repaired and returned C.O.D., with billing for labor, materials, return freight and insurance. Products repaired under warranty will be returned freight prepaid by Technomad to any location within the boundaries of the USA, and freight collect outside the USA.

F. THIS IS THE ONLY WARRANTY GIVEN BY TECHNOMAD AND IS IN LIEU OF ALL OTHER WARRANTIES. ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE, SHALL BE STRICTLY LIMITED IN DURATION TO ONE YEAR FROM THE DATE OF ORIGINAL PURCHASE. UPON EXPIRATION OF THE APPLICABLE WARRANTY PERIOD, TECHNOMAD SHALL HAVE NO FURTHER WARRANTY OBLIGATION OF ANY KIND, EXPRESSED OR IMPLIED. TECHNOMAD SHALL IN NO EVENT BE OBLIGATED FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES THAT MAY RESULT FROM ANY DEFECT OR WARRANTY CLAIM, EXPRESSED OR IMPLIED. Some states do not allow exclusion or limitation of incidental or consequential damages or limitation of how long implied warranties last, so some of the above limitations and exclusions may not apply to you. This warranty provides specific legal rights. The purchaser has implied warranty rights, and you may also have other rights which vary from state to state.

THE VERNAL




Technomad Inc.
800.464.7757
info@technomad.com
www.technomad.com

Thank you for purchasing the Vernal 15, the ultimate compact outdoor loudspeaker

The Design

Technomad is world-renowned for creating loudspeakers which deliver crystal clear, powerful sound in a rugged weatherproof package. The Vernal was created in response to demand from our customers for a smaller loudspeaker built on the same lines as our flagship Berlin loudspeaker. Unlike other compact loudspeakers, the Vernal features a horn-loaded 1" ceramic driver. Most loudspeakers this size either use a dome-tweeter or a "no tweeter" design. These loudspeakers may sound fine in a quiet environment at close range, but when installed outside lack the midrange and high frequency output to deliver high-quality sound. The Vernal 15 projects sound farther and more clearly than any other small loudspeaker on the market. The Vernal is highly efficient, allowing it to make the most of your amplifier. Like all Technomads, the Vernal has a comprehensive 10 year cabinet, 5 year hardware and 2 year electronics warranty.



Frequency Response

The Cabinet

The Vernal packages high-quality sound in a virtually indestructible loudspeaker cabinet. The Vernal cabinet is one solid piece of Mil-Spec polyethylene and is impervious to damage by water, salt, extreme temperatures or UV. A Vernal 15 cabinet will not chip, crack, fade or fail in any other way even after years of exposure to rough environments.

Operation

- The Vernal is available in two different configurations- the standard 8 ohm Vernal 15 and the 70v Vernal 15T (with taps at 10w, 20w, 40w, 60w, and 8 ohms.)

- Please note that the red terminal is the positive (+) terminal and should be wired the positive (+) terminal of your amplifier.
- In normal (8 ohm) operation, be aware of the limitations of your amplifier! If you are wiring two Vernal loudspeakers to the same channel (side) of your amplifier, make sure your amplifier is rated to handle a 4 ohm impedance load. Technomad is not liable for any damage caused by improper operation and installation of our loudspeakers.
- Technomad recommends 12 gauge wire if the loudspeaker will be more than 50 feet from the amplifier.
- In 70v operation (Vernal 15T only), make sure that your amplifier can handle the load your loudspeaker system will place on it. Add up the wattage of the selected tap on each speaker wired on a channel. This number must not exceed the 70v wattage output of the amplifier on that channel. Different speakers on the same channel can have different wattage taps selected, provided that the amplifier can handle the total wattage (i.e. one speaker at 10w, another at 60w = 70w total demand on the amp.)

Installation

The Vernal can be installed in a variety of ways.

As the installer, you are liable for the safe installation of the loudspeaker! If you have any questions, contact an installation professional.

If bracket-mounting the loudspeaker, make sure that the surface you are mounting the bracket to is strong enough to support the loudspeaker's weight. If hanging the loudspeaker, use at least two attachment points. If you are installing the Vernal in an outdoor or other corrosive environment, we strongly recommend covering the terminal block with silicone rubber to prevent corrosion. In the Vernal 15T, after setting the switch to the desired transformer tap, cover the switch with silicone rubber to prevent corrosion.

Available Accessories

- Vernal Multi-position Bracket- This bracket bolts onto the rear of the loudspeaker allowing you to position the loudspeaker in the any orientation.
- Technomad T-shirt- High quality white cotton T-shirt with our logo in black and red.

After you have installed your Vernal 15, please send us a photo of your installation. We are always looking for customer photos to put on our website. If we use yours, we will send you a free T-shirt! Be sure to write your name and address on the back. Send photos to Technomad Inc., 1112 Boylston St., Suite 302, Boston MA 02115 or email GIF or JPG files to sales@technomad.com.