

Technomad MP Series Wall Mount Brackets

WARNING: Mounting and/or suspension of loudspeakers should be done by experienced professionals. The improper installation of a loudspeaker can result in property damage, personal injury and/or liability to the installing contractor. Proper installation of this bracket is the responsibility of the person installing it.

The Vienna and Paris loudspeakers can be mounted with the Vienna/Paris Stainless Bracket. There are also two holes on the standard 2.37" hole pattern featured on the Vernal and other compact speakers.

The Vernal Stainless Bracket is designed for the Vernal loudspeaker as well as any other speaker with a 2.37" hole pattern.

The brackets offer a fixed set of tilt and pan positions for optimum rigidity even under wind load. Note that not all positions can be used depending on speaker orientation. For example, the downward tilt of the Paris in a vertical orientation will be limited by the Berlin cabinet hitting the mounting wall.

Technomad recommends the use of an additional safety cable with the bracket.

Included Stainless Steel Hardware:

Vienna/Paris Bracket

- 2x 5.25" hex bolts
- 2x 3.75" hex bolts
- 4x 1/4-20 nuts
- 4x 1/4-20 lock washers
- 8x 1/4 flat washer

Vernal Bracket:

- 1x 4" 1/4-20 hex bolt
- 2x 1.75" 1/4-20 machine screw
- 3x 1/4-20 nuts
- 3x 1/4-20 lock washers
- 6x 1/4 flat washer

Assembly Details:

The bracket consists of three main elements- the wall plate, the junction and the speaker plate. It is recommended to first install the wall plate using appropriately rated hardware for the application and structure material. Next, attach the speaker plate to the speaker with the included hardware. The junction can then be installed to the speaker plate and the tilt angle can be set. Then the speaker and bracket assembly can be bolted into the wall plate.

